


FOUR DOORS PANTRY CABINET ASSEMBLY INSTRUCTION



Step 1-
 1. Lay cabinet Back Panel (H) on a soft working surface with grooves facing upward. The grooves will be for the Right & Left side Panel (A).

Step 2-
 1. Insert Bottom Panel (D) into the grooves of Side Panels (A) and Back Panel (H)

Step 3-
 1. Attach Front Face (M) onto Bottom Panel (D) and Side Panels (A) making sure panels fit into the grooves of the Front Face (M) and clips are lined up and fully engaged. Insert locking screw into each clip pair and tighten all screws.

2. Attach Toe Kick Plate (J) to Side Panels (A) making sure clips are lined up and fully engaged. Insert locking screw into each clip pair and tighten all screws.

Step 4-
 1. Stand the cabinet upright. Insert shelf clips into the pre-drilled holes on the side panels (A) at desired height and slide in the Shelf (G) making sure the front edge faces out.



www.peakhomeproducts.com

PARTS LIST:	ITEM	QTY
A	ARIGHT /LEFT SIDE PANEL	2
D	BOTTOM PANEL	3
H	BACK PANEL	1
M	FRONT FACE	1
J	TOE KICK PLATE	1
G	SHELF	4